

WATER ACTIVATOR

1066i



DESCRIPTION

Pressing the button in the center of the Ecolor, followed by an audible signal, will initiate a random watering sequence.

ADDITIONAL INFORMATION

Number of users: 1 - 2

Interaction : Yes

Water effect : N/A

Product type : AV-Activator

Installation : Embedded or unifix installation

